

TAYLOR RACE ENGINEERING
 2010 AVENUE G UNIT 914
 PLANO, TX 75074
 PHONE 972-422-0567
 FAX 972-422-8677

SNUBBER PLUNGER
 SETUP FOR FSAE AND
 MSR TRIPOD PN 02002011

DECEMBER 9, 2001

INSTRUCTIONS:

1. CUT PLASTIC FILLER ROD PN 02003165 TO A LENGTH OF 4.350" LESS THAN THE LENGTH OF THE HALF-SHAFT.
2. PRESS PN 02003162 PIVOT PLUG INT (INWARD) END OF AXLE. DRILL THROUGH FOR 1/16" ROLL PIN AND INSTALL 1/16" X 3/4" ROLL PIN (PN RP11634) TO ATTACH PIVOT PLUG
3. INSERT PLASTIC FILLER IN OUTBOARD END FOLLOWED BY SPRING PN 02003164 AND PLUNGER PN 02003161
4. WHEN INSTALLING AXLE IN TRIPOD HOUSING INSURE THAT PLUNGER DOES NOT COCK IN AXLE HOLE. CHECK FOR FREEDOM OF MOTION

